


Configurations: Background noise




How to adjust background noise?

Nuance Audio allows you to **customize the strength of background noises in your environment** while using your Nuance Audio Glasses.

For example, sounds such as traffic, air conditioning, whirring fans, rain, vacuuming, and so on can be adjusted.




To adjust the levels, tap on the Background Noise tab in Home.



You can choose to adjust them in three ways (lowered, standard, and heightened).




How to adjust background noise?




Background noise: Lowered

You'll minimize the background noise, making it less noticeable.



Background noise: Standard

You'll perceive the background noise at its normal level.



Background noise: Heightened

You'll perceive the background noise as louder and clearer.



For the most updated Instructions for Use
please follow this link

[↗ View Instruction for Use](#)