


How to charge



Ready to charge your Nuance Audio Glasses?


Step 1

First connect your Charging Pad using a standard USB-C charger or USB-C power source (minimum 5V) to connect the supplied charging pad and USB-C cable.



Step 2

Then, fold your Nuance Audio Glasses and place them directly on the Charging Pad exactly as shown. The magnets inside the Charging Pad will help position the glasses correctly.







How to know when your glasses are charged?

Orange LED

Charging is in progress.

Green LED

Glasses are fully charged (at least 96%).






Battery level indications

When you pick up your glasses, both the charging pad LED and the frame LED will indicate the battery level for a few seconds.

Red LED

Battery level is lower than 20%.



Green LED

Battery level is higher than 20%.





For the most updated Instructions for Use
please follow this link

[↗ View Instruction for Use](#)